


# EXTENDED WARRANTY PLANS

**MX-11**

**MX-13**



PACCAR offers a wide selection of Extended Warranty Plans for PACCAR Engines to meet your business and application needs. A PACCAR Extended Warranty Plan delivers peace of mind by providing coverage for key engine components for up to seven years beyond the standard warranty coverage.

## PACCAR MX ENGINE STANDARD WARRANTY

<b>COMPREHENSIVE</b> 2 Years/250,000 Miles (400,000 KM)	<b>MAJOR COMPONENT</b> 5 Years/500,000 Miles (800,000 KM)	<b>AFTERTREATMENT</b> 2 Years/250,000 Miles (400,000 KM)
---	---	--

### PACCAR MX ENGINE EXTENDED WARRANTY OPTIONS

<span style="color: #0070C0;">●</span> <b>PACCAR PREMIUM</b> Up to 5 Years/ 500,000 Miles or 7 Years/ 200,000 Miles	<span style="color: #FF9900;">●</span> <b>PACCAR PROTECTION 1</b> Up to 5 Years/ 500,000 Miles (800,000 KM)	<span style="color: #00B0F0;">●</span> <b>PACCAR PROTECTION 2</b> Up to 5 Years/ 500,000 Miles (800,000 KM)	<span style="color: #E91E63;">●</span> <b>MAJOR COMPONENT PLAN</b> Up to 7 Years/ 700,000 Miles (1,200,000 KM)	<span style="color: #FFD700;">●</span> <b>AFTERTREATMENT PLAN</b> Up to 5 Years/ 500,000 Miles (800,000 KM)
--	--	--	---	--

### ADDITIONAL COVERAGE OPTIONS

Flywheel	●				
Flywheel Housing	●				
Fuel Control Valve	●				
Fuel Filter Module	●				
Fuel Hand Primer Pump	●				
Fuel Lift Pump	●				
Fuel Lines (High Pressure) Pump To Rail	●				
Fuel Lines (High Pressure) Rail To Injector	●				
Fuel Lines (Low Pressure)	●				
Oil Fill Tube And Cap	●				
Sensor EGR Temperature	●				
Sensor, Pressure/Temp/Humidity (Before Turbocharger)	●				
Air Inlet Pipes (Before & After Turbocharger)	●				
Electrical Harness Supplied With Engine	●				
Air Compressor	●	●			
Common Fuel Rail	●	●			
Electronic Engine Sensors	●	●			
Engine Brake	●	●			
Fuel Injectors	●	●			
Hp Fuel Unit Pumps	●	●			
Sensor, Exhaust Manifold Pressure	●	●			
Sensor, Intake Boost Pressure	●	●			
Turbocharger	●	●			
Water Pump	●	●			
Camshaft And Bushings	●	●	●		
Connecting Rod And Bearings	●	●	●		
Crankshaft And Bearings	●	●	●		
Cylinder Block Assembly	●	●	●		
Cylinder Head Assembly	●	●	●		
Engine Control Module	●	●	●		
Exhaust Gas Recirculation Cooler	●	●	●		
Exhaust Gas Recirculation Mixer Valve	●	●	●		
Gaskets, Seals, O-rings, Silicon Sealant	●	●	●		
Gear Train	●	●	●		
Oil Cooler Assembly	●	●	●		
Oil Pan	●	●	●		
Oil Pump Assembly	●	●	●		
Piston Liners	●	●	●		
Piston Rings	●	●	●		
Valve Train	●	●	●		
Connecting Rod Assembly				●	
Crankshaft				●	
Cylinder Block Assembly				●	
Cylinder Head				●	
Flywheel Housing				●	
Gear Train				●	
Camshaft				●	
Water Pump Housing				●	
Aftertreatment Control Module					●
Diesel Exhaust Fluid Dosing ECM					●
Decomposition Pipe					●
Diesel Exhaust Fluid Pump Module					●
Diesel Exhaust Fluid Dosing Module & Injector					●
Diesel Particulate Filter Assembly					●
Exhaust Gas Recirculation Temperature Sensor					●
Hydrocarbon Doser					●
Oxygen Sensor					●
Selective Catalytic Reduction Assembly					●
Select Diesel Particulate Filter and Selective Catalytic Reduction Sensors					●

Aftertreatment Plan optional with PACCAR Premium Plan and PACCAR Protection Plan 1 (Not Available with Protection Plan 2)

PACCAR Inc.  
P.O. Box 1518  
Bellevue, WA 98009

PACCAR POWERTRAIN

Terms and Conditions: PACCAR Engine extended warranty plans can be purchased in yearly and 100,000 mile (160,000 KM) increments. Plan coverage durations and mileages vary with engine horsepower and intended service. Consult with your PACCAR Engine dealer at time of ordering for details. This document is to be considered a summary of coverages and to be used for reference only and is not a binding document. For full warranty coverage details, the respective legal document should be referenced.

\* Select components classified as Emission Related Parts by the U.S. Environmental Protection Agency are covered to 5 years/100,000 miles.